

Balance Shower Faucet

Installation Manual

W-4.3(ES)

Warranty Duration

All parts of this faucet system are warranted to the original purchaser to be free from defects in material and workmanship for a lifetime.

Repair and Replacement

If the product has defects in material and workmanship within the warranty period, we will repair or replace the product free of charge. However, you may be required to provide the invoice when requesting repairs or replacement from us.

Exclusions

We shall not be responsible for the following cases:

- Damage to the product caused by improper installation, misuse, unauthorized repair or replacement, or abuse (including damage during shipment).
- Damage to the product caused by improper dismantlement after installation.
- Damage resulting from abnormal water pressure and impurities in water pipes is not covered under this warranty.
- Rust on the product due to insufficient care and maintenance is not covered under this warranty.
- Damage caused by natural disasters such as fire, flood, earthquake, electric storms, etc., is not covered under this warranty.

I hope this helps! If you have any further questions or concerns, please let me know.

Having Trouble? Contact us.

✉ Email: info@faucetsupport.com

📞 Toll Free: 1-888-969-6880



CEC **FCC** **CE** **RoHS**



M6646
Model:A

M6502
Model:B

CONTENT

1.Two-function Rain Shower System----- (1-10)

CONTENIDO



1.Sistema de Ducha de Lluvia de Dos Funciones----- (11-20)

◆ Installation and maintenance matters

- 1.Check the accessories list to verify that all parts are complete in this package.
- 2.Do not disassemble the main body by yourself.
- 3.Connect inlet pipes to supply valves.
- 4.Make sure inlet pipes and supply valves have no impurities and are cleaned, with no impurities in the pipeline.
- 5.After installation, check all joints for leakages.
- 6.Do not leave the rain shower system exposed to a severely corrosive environment.

Do's


- 1.In order to keep the mixer surface bright, please clean the mixer regularly.
- 2.Rinse the faucet with clean water and wipe it with a soft cotton cloth.
- 3.Use one of the following cleaners to remove dirt from the surface:
 - a.Mild liquid cleaner.
 - b.Colorless glass cleaner and powder cleaner that do not cause abrasion and can be dissolved completely.
 - c.Polish liquid that does not cause abrasion.



Don'ts

- a.Avoid using cleaning powder, harsh cleaning chemicals, brushes and coarse cloth to prevent scratching and friction.
- b.Do not use acid cleaners to clean the faucet as they may cause surface corrosion of the faucet. If the faucet is exposed to harmful acid substances, please rinse it immediately with water.


TOOLS NEEDED:



◆ Two-function Rain Shower System


Model:A

Accessories List




No.	Part name	Qty	No.	Part name	Qty
1	Shower head	1	10	Main body	1
2	Shower arm	1	11	Connector	1
3	Shower arm cup	1	12	Cup	1
4	Hand shower holder	1	13	Main body spare parts	4
5	Shower hand	1	14	Instruction manual	1
6	Shower hose	1	15	Gloves	2
7	Water diverter	1	16	Handle parts	1set
8	Handle	1	17	Shower holder parts	1set
9	Deck plate	1			

◆ Essential dimensions & water pipe line




◆ The installation depth of shower holder and body jet




The thickness of the tile must be calculated for installation.

Connector size of male thread: USA: 1/2"-14NPT, Canada: 1/2"-14NPT, Europe: G1/2".

◆ Installation The Hand Show Holder



Install the decorative cover under the water spout, and then tighten it into the wall using the waterproof tape.




Step 1. First, use anchors to screw the pipe holder into the wall.

Step 2. Remove the two screws from the shower seat.

Step 3. Insert the shower seat into the pre-installed copper fittings on the wall, then secure the shower seat with the two screws you removed earlier.

◆ The installation of the overhead shower.




1. Connect shower arm with the cover before screwing arm into riser connection to prevent damage.
2. Fix shower head onto shower arm and apply tape to pipe threads on both ends.
3. Do not over tighten shower head. It is 360° swivel connection.

◆ Two-function Rain Shower System

Model:B


Accessories List




No.	Part name	Qty	No.	Part name	Qty
1	Waterfall spout	1	9	Deck plate	1
2	Spout copper	1	10	Main body	1
3	Hand shower holder	1	11	Main body spare parts	4
4	Hand shower holder cup	1	12	Instruction manual	1
5	Shower hand	1	13	Gloves	2
6	Shower hose	1	14	Handle parts	1set
7	Water diverter	1	15	Shower holder parts	1set
8	Handle	1	16		

◆ Essential dimensions & water pipe line

Unit: mm/inch




◆ The installation depth of shower holder and body jet



The thickness of the tile must be calculated for installation.

Connector size of male thread: USA: 1/2"-14NPT, Canada: 1/2"-14NPT, Europe: G1/2".

◆ Installation The Hand Show Holder



Step1. Remove the male connector from the top of the shower holder

(do not damage the gasket, otherwise it will leak).


Step2. Screw the thread into the water pipe inside the wall

Step3. Screw the main body into the thread.

Step4. Rotate and fix the body with the special-shaped wrench

Step5. Connect hand shower and the hose.

◆ Install The Tub Spout




Step1: Connect the copper connector to the bathtub spout and wrap it with waterproof tape.

Step2: Install the round decorative cover.


Step3: Rotate the bathtub spout to connect with the internal thread on the wall.

◆ Installation Depth Of Main Body



- Notice:
1. The installation depth of the main body should be no less than $2\frac{9}{16}$ " (65mm) and no more than $2\frac{15}{16}$ " (75mm), including the thickness of the tile. Otherwise, the deck plate cannot be installed.
 2. The opening size of ceramic tile shall be smaller than the deck plate size.


◆ Piping Instructions Before Tiling



1. As shown in the figure, the inlet and outlet pipes are pre-buried. Please pay attention to the correct direction when installing the pre-buried main body.
2. Before tiling, turn on the water to test whether the left and right inlet pipes are tightly connected without leakage. Then, adjust the flow switch to the "on" position to check for leaks in the mixed outlet pipes.

◆ Main Body Valve Installation


Step1



1. Make marks according to the size of the main body valve, and then drill anchors into the wall (concrete wall).
 2. Lock the main body to wood directly with screws (wood wall).
 3. When installing the main body, please mark the UP side up and do not install it upside down.
- ▲ Please note that the level meter should be parallel to the wall; otherwise, the deck plate cannot be installed.

◆ Main Body Water Outlet Switch Control


Model:A



1. Open the water valve and check for any leakage
2. Turn the handle upwards to open the water valve. The turning angle can control the water outflow rate. Then, the user can turn it to the left or right to control the water temperature, where the left is for hot water and the right is for cold water.
3. The switch valve can alternate the water outlet between the shower head, body jet, and handheld shower

◆ Main Body Water Outlet Switch Control




Model:B



1. Open the water valve and check for any leakage
2. Turn the handle upwards to open the water valve. The turning angle can control the water outflow rate. Then, the user can turn it to the left or right to control the water temperature, where the left is for hot water and the right is for cold water.
3. The switch valve can alternate the water outlet between the shower head, body jet, and handheld shower

◆ Instalación y cuestiones de mantenimiento

- 1.Verifique la lista de accesorios para comprobar que todas las partes están completas en este paquete.
- 2.No desmonte el cuerpo principal por sí mismo.
- 3.Conecte las tuberías de entrada a las válvulas de suministro.
- 4.Asegúrese de que las tuberías de entrada y las válvulas de suministro no tengan impurezas y estén limpias, sin impurezas en la tubería.
- 5.Después de la instalación, revise todas las juntas en busca de fugas.
- 6.No deje el sistema de ducha expuesto a un ambiente severamente corrosivo.




Hacer

- 1.En para mantener la superficie de la batidora brillante, limpie el mezclador regularmente.
- 2.inse el grifo con agua limpia y límpielo con un suave ropa de algodón.
- 3.Use uno de los siguientes limpiadores para eliminar la suciedad de la superficie:
A.Mild Liquid Cleaner.
B. Cleaner de vidrio sin color y limpiador de polvo que no causar abrasión y se puede disolver por completo.
C. Polish Líquido que no causa abrasión.

No es decir

- A.Valte con polvo de limpieza, productos químicos de limpieza duros, cepillos y tela gruesa para evitar rascar y fricción.
- B. No use limpiadores de ácidos para limpiar el grifo, ya que pueden causar corrosión superficial del grifo. Si el grifo está expuesto a sustancias ácidas dañinas, enjuague inmediatamente con agua.


HERRAMIENTAS NECESARIAS:



◆ Sistema de Ducha de Lluvia de Dos Funciones

Modelo: A

Lista de Accesorios




N.º	Nombre de la pieza	Cantidad	N.º	Nombre de la pieza	Cantidad
1	Alcachofa de la ducha	1	10	Cuerpo principal	1
2	Brazo de ducha	1	11	Conector	1
3	Taza de brazo de ducha	1	12	Taza	1
4	Asiento fijo de ducha	1	13	Piezas de repuesto del cuerpo principal	4
5	Ducha de mano	1	14	Manual de instrucciones	1
6	Manguera de ducha	1	15	guantes	2
7	Desviador de agua	1	16	Partes del mango	1juego
8	manija	1	17	Partes del soporte de ducha	1juego
9	placa de cubierta	1			


◆ Dimensiones esenciales & línea de tubería de agua

Over Head shower

Unidad: mm/pulgada




◆ La profundidad de instalación del soporte de ducha y del chorro para el cuerpo




El grosor del azulejo debe ser calculado para la instalación.

Tamaño del conector de rosca macho: EE. UU.: 1/2"-14NPT, Canadá: 1/2"-14NPT, Europa: G1/2".

◆ Instalación del Soporte para la Ducha de Mano



Instala la cubierta decorativa debajo del surtidor de agua, y luego apriétala contra la pared usando la cinta impermeable.




Paso 1. Primero, usa anclajes para atornillar el soporte del tubo en la pared.

Paso 2. Retira los dos tornillos del asiento de la ducha.

Paso 3. Inserta el asiento de la ducha en los accesorios de cobre preinstalados en la pared, luego asegura el asiento de la ducha con los dos tornillos que retiraste anteriormente.

◆ La instalación de la ducha de techo.




1. Conecte el brazo de la ducha con la cubierta antes de atornillar el brazo en la conexión del elevador con prevenir el daño.
2. Fije el cabezal de la ducha en el brazo de la ducha y aplique cinta adhesiva para las roscas de tubos en ambos extremos.
3. No revolotear la cabeza de ducha. Es una conexión giratoria de 360 °.

◆ Sistema de Ducha de Lluvia de Dos Funciones

Modelo: B


Lista de Accesorios




N.º	Nombre de la pieza	Cantidad	N.º	Nombre de la pieza	Cantidad
1	Surtidor de cascada	1	9	placa de cubierta	1
2	Pico de cobre	1	10	Cuerpo principal	1
3	Asiento fijo de ducha	1	11	Piezas de repuesto del cuerpo principal	4
4	Copia decorativa para asiento fijo de ducha	1	12	Manual de instrucciones	1
5	Ducha de mano	1	13	guantes	2
6	Manguera de ducha	1	14	Partes del mango	1juego
7	Desviador de agua	1	15	Partes del soporte de ducha	1juego
8	manija	1	16		

◆ Dimensiones esenciales & línea de tubería de agua

Unidad adm/m/m/pulgada



◆ La profundidad de instalación del soporte de ducha y del chorro para el cuerpo




El grosor del azulejo debe ser calculado para la instalación.

Tamaño del conector de rosca macho: EE. UU.: 1/2"-14NPT, Canadá: 1/2"-14NPT, Europa: G1/2".

◆ Instalación del Soporte para la Ducha de Mano

Paso 3




Paso 4


Paso 1



Paso 2



Paso 5



Paso 1. Retire el conector macho de la parte superior del soporte de la ducha (no dañe la junta, de lo contrario, habrá fugas).


Paso 2. Enrosque la rosca en la tubería de agua dentro de la pared

Paso 3. Enrosque el cuerpo principal en la rosca.

Paso 4. Rote y fije el cuerpo con la llave especial.

Paso 5. Conecte la ducha manual y la manguera.

◆ Instalar el Surtidor de la Bañera





Paso 1: Conecta el conector de cobre al surtidor de la bañera y envuélvelo con cinta impermeable.

Paso 2: Instala la cubierta decorativa redonda.


Paso 3: Gira el surtidor de la bañera para conectarlo con la rosca interna en la pared.

◆ Profundidad de Instalación del Cuerpo Principal



- Aviso:
1. La profundidad de instalación del cuerpo principal no debe ser inferior a $2\frac{9}{16}$ " (65 mm) y no más de $2\frac{15}{16}$ " (75mm), incluyendo el grosor del azulejo. De lo contrario, la placa de cubierta no podrá ser instalada.
 2. El tamaño de apertura del azulejo cerámico debe ser menor que el tamaño de la placa de cubierta.


◆ Instrucciones de Tubería Antes de Colocar Azulejos



1. Como se muestra en la figura, las tuberías de entrada y salida están pre-enterradas. Por favor, preste atención a la dirección correcta al instalar el cuerpo principal pre-enterrado.
2. Antes de colocar los azulejos, abra el agua para probar si las tuberías de entrada izquierda y derecha están conectadas herméticamente sin fugas. Luego, ajuste el interruptor de flujo a la posición "on" para comprobar si hay fugas en las tuberías de salida mezcladas.

◆ Instalación de la Válvula del Cuerpo Principal

Paso 1




(Pared de concreto)

(pared de madera)

1. Marque según el tamaño de la válvula del cuerpo principal y luego perfore para colocar los anclajes en la pared (pared de concreto).
 2. Fije directamente el cuerpo principal a la madera con tornillos (pared de madera).
 3. Al instalar el cuerpo principal, por favor marque el lado UP hacia arriba y no lo instale al revés.
- ▲ Tenga en cuenta que el nivel debe estar paralelo a la pared; de lo contrario, la placa de cubierta no podrá ser instalada.

◆ Control del Interruptor de Salida de Agua del Cuerpo Principal


Modelo:A



1. Abre la válvula de agua y verifica si hay alguna fuga.
2. Gira la manija hacia arriba para abrir la válvula de agua. El ángulo de giro puede controlar la tasa de flujo de salida del agua. Luego, el usuario puede girarlo hacia la izquierda o hacia la derecha para controlar la temperatura del agua, donde la izquierda es para agua caliente y la derecha es para agua fría.
3. La válvula de cambio puede alternar la salida de agua entre la ducha, el chorro corporal y la ducha manual.

◆ Control del Interruptor de Salida de Agua del Cuerpo Principal

Modelo:B



1. Abre la válvula de agua y verifica si hay alguna fuga.
2. Gira la manija hacia arriba para abrir la válvula de agua. El ángulo de giro puede controlar la tasa de flujo de salida del agua. Luego, el usuario puede girarlo hacia la izquierda o hacia la derecha para controlar la temperatura del agua, donde la izquierda es para agua caliente y la derecha es para agua fría.
3. La válvula de cambio puede alternar la salida de agua entre la ducha, el chorro corporal y la ducha manual.